


2. Rear Panel



A. Audio Input/ Output	Stereo audio connections to external audio equipment.
B. MIDI Input / Thru / Output	MIDI connections to external MIDI equipment or computer.
C. Keyboard	Connects to piano keyboard cable.
D. DC Jack	AC power adapter plugs in here.