























AMERICAN STANDARD STRATOCASTER 0107400/7402

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
					← 5 WAY SWITCH POSITION
T1	T1&T2	T2	T2	T2	← TONE CONTROL
					← NECK PICKUP
					← MIDDLE PICKUP
					← BRIDGE PICKUP
	← PICKUP IS ON				← PICKUP IS OFF

