

# Jimmy Page Style Wiring



## PUSH/PULL CONTROLS

Bridge volume: splits bridge pickup

Neck volume: splits neck pickup

Bridge tone: puts bridge & neck pickups out of phase with each other

Neck tone: puts bridge & neck pickups in series together



**Seymour  
Duncan®**

5427 Hollister Ave. • Santa Barbara, CA. 93111

Phone: 805.964.9610 • Fax: 805.964.9749 • Email: [wiring@seymourduncan.com](mailto:wiring@seymourduncan.com)