

CLASSIC PLAYER BAJA TELECASTER[®], 014-1502

WIRING DIAGRAM

